

CF Flashlight

User Manual

V 1.1.3.0

1. The **CF Flashlight** is a Windows Phone 10 application that will use the phone's camera flash to:
 - a. Act as a flashlight.
 - b. Send Morse code, either manually (using the camera button on the side of the phone) or automatically by typing in the message to send and clicking on the send button.
 - c. Display a strobe light.
 - d. Automatically send a distress signal (SOS).

The startup screen with these capabilities is shown in Figure 1.




Figure 1- Startup Screen

- The user can also display the standard Morse code by clicking on the “Show Morse Code” button




Figure 2- Morse Code display.

- Errors** – If an error occurs, a message box will popup. Normally, the error message will be self-explanatory. If an unexpected error happens, please email the text of the error to:

corporate@cfsw.biz

- Please email any problem descriptions or improvement suggestions to:

corporate@cfsw.biz